

TIPS 'N' TRICKS



QM-EZTAQUEMED FULL WALL INSTALLATION

Easy to install, easily removed! Just follow the simple step-by-step below and be sure to get the job done right.

Prepare Wall

- 1 Wipe down entire area of wall. Mr. Clean® Magic Eraser recommended (dampend). Allow wall to dry.
- 2 With the print side down, pull back the liner about 8 inches from the top exposing the adhesive. Crease liner as shown.
- 3 **Critical Step:**
2 people recommended. Starting at the top of the wall, Position the exposed adhesive side to the wall flush with the ceiling. Burnish EZTAQUEMED with the roller/squeegee working from the center outward, side to side pushing out any air pockets, while the other person pulls the liner down directly toward the floor.
- 4 Continue this method until reaching the end of media at the bottom. It's that easy.

